



# 3.0 Messages

- 3.1 Receive and read messages
- 3.2 Status of Messages
- 3.3. Search messages
- 3.4 Replying to messages

# 3.1 Receive and read messages




ers  
wed  
lica  
with the tester  
y time.  
message buttons.

Frag  
5 Fra  
St  
sub  
Den  
18 Fr  
St  
sub

# 3.2 Status of Messages


Within the message list, the statuses of messages are displayed using various icons on the left edge of the display:

- Blue “dot” icon: Message not yet read by the tester.
- Green “arrow” icon: Response from the tester has been successfully sent and arrived in the Control Center
- Gray “arrow” icon: Response from the tester has been sent, but has not yet arrived in the Control Center




# 3.3. Search messages

Within the message list, you can search for specific messages using the search bar.



# 3.4 Replying to messages

The tester can only reply to a comment if the planner has previously specified this. If the planner has given the option to reply, there is a reply button below the message history, which the tester



If the planner has not released the reply option, you can tell by the information displayed at the bottom "The reply option was not given for this message".

12:30



< Messages

Feedback Details



3

**Transmission**  
Drive - IN 6290 / Garner Matthew  
04-SUV\_FM\_1

Transmission slips out of gears.

05. Oct 2023

**Benjamin Higgins**

Please contact the responsible mechanic and if possible continue to observe how the transmission reacts.

15:20

The option to answer has not been activated for this message.